

Photometer AL200



Designed to meet the latest technical requirements, the AL200 photometer can be used in practically every area of water analysis.

The high-precision optics with its top-quality interference filters uses long-term stable LEDs as light-source. Because there are no moving parts, the entire measurement device requires absolutely no maintenance.

Precise and reproducible analysis results are obtained in a short time. The units impress with their user-friendliness, ergonomic design, compact dimensions and easy handling.

The tests are conducted using either AQUALYTIC® tablet reagents with long-term stability and a guaranteed minimum 5 or 10 year shelf life or using liquid reagents.

12

Highlights

- Scroll Memory
- Infra-red interface
- Real-Time-Clock and Date
- Calibration Mode
- Backlit Display
- Storage Function
- One Time Zero (OTZ)
- Waterproof^{*)}

^{*)} as defined in IP 68, 1 hour at 0.1 meter

Scroll Memory (SM)

For multi-parameter instruments, the order of the various methods is determined. To avoid unnecessary scrolling for the required test method, the instrument memorizes the last method used before switching off the instrument. When the instrument is switched on again, the scroll list comes up with the last used test method first. This allows for faster access to favored methods.

Zero Setting (OTZ)

It is not necessary to zero the instrument each time. The zero setting is held in memory until the device is turned off (One Time Zero - OTZ). The zero setting can be confirmed whenever it is useful.

Manufacturers Test Certificate M

Besides the "Certificate of Compliance" which is supplied with the AL100, manufacturers test certificates M are available at cost on request. Manufacturers test certificates M are individually supplied per instrument and per method.

The manufacturers test certificate M has to be ordered together with the new instrument and cannot be delivered at a later stage.

➔ Reagents (order codes), please see pages 34 onwards

Technical data

Optics	LEDs, interference filters (IF) and photo sensor in transparent sample chamber. Depending on the version, up to 3 different interference filters are used. Wavelength specifications of interference filters: 430 nm $\Delta\lambda = 5$ nm 530 nm $\Delta\lambda = 5$ nm 560 nm $\Delta\lambda = 5$ nm 580 nm $\Delta\lambda = 5$ nm 610 nm $\Delta\lambda = 6$ nm 660 nm $\Delta\lambda = 5$ nm
Wavelength Accuracy	± 1 nm
Photometric Accuracy⁴⁾	3% FS (T = 20°C – 25°C)
Photometric Resolution	0.01 A
Power Supply	4 batteries (AA), capacity approx. 53 hours or 15000 tests (continuous operation without display lighting)
Auto - OFF	automatic switch-off
Display	backlit LCD (on keypress)
Storage	internal ring memory for 16 data sets
Interface	infrared interface for test data transfer to IRiM
Additional feature	real time clock and date
Calibration	factory calibration and user calibration. Reset to factory calibration possible
Dimensions	190 x 110 x 55 mm (L x W x H)
Weight	basic unit approx. 455 g (with batteries)
Environmental conditions	temperature: 5–40°C rel. humidity: 30–90% (non condensing)
Approval	CE

⁴⁾ tested with standard solutions

Accessories

Item	Code
Set of 12 round vials with lid Height 48 mm, Ø 24 mm	197620
Set of 5 round vials with lid Height 48 mm, Ø 24 mm	197629
Adapter for round vials ø 16 mm	19802220
Membrane filter set for use when preparing samples, 25 membrane filters, 0,45 µm, 2 syringes 20 ml	366150
Vial stand for 6 round vials Ø 24 mm, acrylic glass	418951
Vial stand for 10 vials (Ø 16 mm or □ 13,5 mm), acrylic glass	418957
Cleaning cloth for vials	197635
Set of 12 sealing rings for round vial ø 24 mm	197626
4 batteries (AA)	1950025
Battery lid	19802241
Measuring beaker, volume 100 ml	384801
Plastic stirring rod, 13 cm length	364100
Plastic stirring rod, 13 cm length, (10 pc.)	364120
Plastic stirring rod, 10 cm length	364109
Plastic stirring rod, 10 cm length, (10 pc.)	364130
Infra-red data transfer modul IRiM	4214050



Delivery Content

Each AL200 is supplied in a sturdy plastic case with 4 batteries (AA), 3 round vials (glass) with lids, 1 stirring rod, 1 brush & 1 syringe, tablet reagents and/or liquid reagents, warranty information, certificate (Certificate of Compliance) and instruction manual.

You can find updated information on parameters and measuring ranges on our website at www.aqualytic.de

Photometer AL200

Single-Parameter

Test	Code
COD , tube tests, without reagents 0 - 150 mg/l O ₂ (ø 16 mm) 0 - 1500 mg/l O ₂ (ø 16 mm) 0 - 15000 mg/l O ₂ (ø 16 mm)	42892502

2in1

Test	Code
Chlorine, pH , tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 6.5 - 8.4 pH	42889402
Chlorine, pH , liquid reagents 0.02 - 4 mg/l Cl ₂ / 6.5 - 8.4 pH	42889412
Copper, pH tablet reagents 0.05 - 5 mg/l Cu / 6.5 - 8.4 pH	42872102
Hydrogen peroxide, pH (no OTZ) liquid reagents 1 - 50 mg/l H ₂ O ₂ / 40 - 500 mg/l H ₂ O ₂ 6.5 - 8.4 pH	42888102

3in1

Test	Code
Chlorine, pH, Bromine tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 6.5 - 8.4 pH / 0.05 - 13 mg/l Br	42861802
Chlorine, pH, Cyanuric acid tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 6.5 - 8.4 pH / 0 - 160 mg/l cyanuric acid	42860102
Chlorine, pH, Cyanuric acid liquid reagents for chlorine and pH 0.02 - 4 mg/l Cl ₂ / 6.5 - 8.4 pH 0 - 160 mg/l cyanuric acid	42882002
Chlorine, pH, Alkalinity-M tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 6.5 - 8.4 pH / 5 - 200 mg/l CaCO ₃ (TA)	42889002
Chlorine, pH, Alkalinity-M liquid reagents for chlorine and pH 0.02 - 4 mg/l Cl ₂ / 6.5 - 8.4 pH 5 - 200 mg/l CaCO ₃ (TA)	42889302

4in1

Test	Code
Chlorine, pH, Cyanuric acid, Alkalinity-M tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 6.5 - 8.4 pH / 0 - 160 mg/l cyanuric acid 5 - 200 mg/l CaCO ₃ (TA)	42860502
Chlorine, pH, Cyanuric acid, Alkalinity-M liquid reagents for chlorine and pH 0.02 - 4 mg/l Cl ₂ / 6.5 - 8.4 pH 0 - 160 mg/l cyanuric acid / 5 - 200 mg/l CaCO ₃ (TA)	42860542

5in1

Test	Code
Chlorine, pH, Cyanuric acid, Alkalinity-M, Calcium hardness tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 6.5 - 8.4 pH / 0 - 160 mg/l cyanuric acid 5 - 200 mg/l CaCO ₃ (TA) / 0 - 500 mg/l CaCO ₃ (CaH)	42861202

6in1

Test	Code
Chlorine, Bromine, pH, Cyanuric acid, Alkalinity-M, Calcium hardness tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 0.05 - 13 mg/l Br / 6.5 - 8.4 pH 0 - 160 mg/l cyanuric acid / 5 - 200 mg/l CaCO ₃ (TA) 0 - 500 mg/l CaCO ₃ (CaH)	42861902
Chlorine, pH, Cyanuric acid, Alkalinity-M, Copper, Iron tablet reagents 0.01 - 6.0 mg/l Cl ₂ / 0.1 - 10 mg/l Cl ₂ * 6.5 - 8.4 pH / 0 - 160 mg/l cyanuric acid 5 - 200 mg/l CaCO ₃ (TA) / 0.05 - 5 mg/l Cu 0.02 - 1 mg/l Fe ^{2+/3+}	42862102

* Delivery without reagents for measuring range 0.1 - 10 mg/l Cl₂

Data Transfer

The optional available IRiM (infra-red interface modul) uses modern infra-red technology to transmit measurement data from the AL100 photometer to one of 3 optional interfaces. These interfaces can be used to connect to a PC, a USB printer¹⁾ or alternatively a serial printer²⁾.

The unit is supplied complete with data logging software providing easy and rapid transfer of data to the PC. As an option, the data can be saved as an Excel sheet or a .txt file.

Measurement data can quickly be printed out, using a specified¹⁾ USB or alternatively a printer with a serial plug-in connected to the IRiM.

Applicable for the following operating systems:
Windows XP, Windows Vista and Windows 7.

¹⁾ USB printer: HP Deskjet 6940 ; ²⁾ each ASCII printer



Verification Standard Kit

The verification standard kit for the AL200 is designed to assure the user of the accuracy and the reliability of the results. The kit contains one zero standard, 6 different vials for checking 6 different wave lengths and allows checking the complete range of AL200 photometers.

The shelf life of the verification standard kit is two years from the date of production, provided that storage and use are in accordance with the instructions provided. Measurements are taken in mAbs.

Verification Standard Kit 4215670



Reference Standard Kits for AL200

The reference standards are designed to check the accuracy and the reliability of the results.

It is not possible to calibrate the photometer with the reference standards.

The shelf life of reference standards is two years from the date of production, provided that storage and use are in accordance with the instructions provided.

Kit Chlorine for instruments with tablet / liquid reagent 0.2* and 1.0* mg/l 4275650

Kit Chlorine for instruments with tablet / liquid reagent 0.5* and 2.0* mg/l 4275655

Kit Chlorine for instruments with tablet / liquid reagent 1.0* and 4.0* mg/l 4275656

Kit pH for instruments with tablet / liquid reagent 7,45* pH 4275670

* Approximate figure, actual figure specified in certificate of analysis enclosed

